


Start the Logitech Harmony TM configuration software and click on "Devices".




Click on "Add Device".




Select "Home Automation" and then select "Light Controller".




Select manufacturer "Velbus".



Enter the model "VMB8IR" and complete the wizard



Add labels to the buttons; remove unused channels (if any) and change the order of the buttons to match your own preferences.



Complete the wizard and update the remote control.

Tip:

Buttons that are linked to the LCD only transmit the Infrared code briefly. Sometimes a button with a longer response time (1, 2 or 3 seconds) is needed or one wants to control a dimmer with it. To achieve this, the code can be linked to a standard button or an action for lighting control should be added. For this last method all buttons must be redefined as described in "adding devices". Now all buttons will transmit IR codes as long as the button is operated.