

Priva III Quick User Guide

- 1 LED indicator
- 2 ON / OFF
- 3 3.5mm audio jack
- 4 Multi-Function Button (MFB)
- 5 USB in / charging socket
- 6 Magnetic base
- 7 3M sticker

Pair and connect

1 Set

Plug in the charging cable for power and switch the button to "ON"

2 Pair

PAIRING MODE*
Upon first use, LED will blink **BLUE & RED** alternately. Get headset or speaker into **PAIRING MODE***

3 Connect

Keep the devices close and wait until the LEDs slow down.

4 Multi-link

Press and hold 1s until LED blinks **BLUE & RED** alternately. Get the second headset into pairing mode, then repeat step 3

*PAIRING MODE: Discoverable mode for Bluetooth devices, normally the LED blinks 2 or 3 times per second or blinks 2 colors alternately.

Connect Priva III to an audio source

TV with 3.5mm headphone jack: Connect Priva III to the TV using the included 3.5mm audio cable

3.5 mm audio cable 1

TV with RCA ANALOG* OUT: Connect Priva III to the TV using the included RCA cable

3.5 mm audio cable RCA cable 2

*Find the correct ANALOG output: You can connect wired earphones with the RCA cable to test whether the sound is normal.

TV WITHOUT RCA analog out or headphone jack: Connect Priva III to the TV with a Digital to Analog Audio Converter (please buy separately)

TV-BACK

Digital Optical Cable 3

Digital Audio Converter (please buy separately)

Use for PC / Laptop

Priva III supports Micro USB Audio input for PC / Laptop. Most TVs can't be used in this way.

1

Connect Priva III to PC via the supplied Micro USB sync charge cable

Note: The connecting cable must have both DATA SYNCING and CHARGING capabilities

2

Turn on - Switch the button to "ON". Pair and connect Priva III with Headphones as above

3

Open Volume Mixer
Playback devices
Recording devices
Sounds
Troubleshoot sound problems

Right-click the speaker icon on right-corner of screen. And select "Playback devices".

4

Set "Avantree Priva III" as "Default Device".

Status of Priva III by the LED indications

Status	LED indicator
Power on	LED flashes BLUE for 1 second
Pairing mode	LED blinks BLUE and RED alternately
Connected with SBC codec	LED flashes BLUE once every 5 seconds
Connected with Fast stream codec	LED flashes BLUE twice every 5 seconds
Connected with aptX codec	LED flashes WHITE once every 5 seconds
Connected with aptX-LL codec	LED flashes WHITE twice every 5 seconds
Reconnect	LED flashes BLUE once every 2 seconds
Restored factory default settings	LED flashes BLUE for 2 seconds

Priva III FAQs and Tips

- Why is there still a delay?**
This could be because your headphones or receiver don't support aptX Low Latency Codec.
- How do you reconnect?**
There is no need to pair Priva III each use. It will auto reconnect to the last paired headphones/receiver once you power on both devices and wait for 5~10s.

For other paired headphones / receivers, they may auto reconnect to Priva III after waiting 5~10s once powered on. Otherwise, please put both devices into pairing mode.
- How do you reset (clear paired device info) Priva III?**
If Priva III can't pair with your Bluetooth devices suddenly, please try to reset it:
Step 1. Get Priva III into pairing mode - press and hold MFB for 1 second until the LED flashes **BLUE** and **RED** alternately.
Step 2. Press and hold the MFB button for 5s, then you will see the BLUE LED is on for 2s.
Step 3. Then it will enter pairing mode automatically
- What kind of charger can be used for Priva III?**
You can connect Priva III via the supplied micro USB cable to your own USB chargers (wall charger/travel charger/mobile phone charger, etc.) with 5V/500mA-1A, or PC/TV USB port.